

- 8.1.696 START\_DATA\_FUNCTION — (text) name of <data\_function> group.
  - 8.1.697 START\_DATA\_MANIPULATION — (text) name of group of sequential BOOLEAN and/or <data\_fracture> operations. The output pattern data from the first operation is the input pattern data for the next operation and so on. The data field must be a unique identifier within <mask\_order> as the results of one <data\_manipulation> may be referenced by another.
  - 8.1.698 START\_DEFECT\_DEFINITION — (text) name of <defect\_definition> group.
  - 8.1.699 START\_DEFECT\_MEASUREMENTS — (text) name of <defect\_measurements> group.
  - 8.1.700 START\_ETCH\_DEPTH\_MEASUREMENTS — Indicates the beginning of etch depth measurements within <phase\_shift\_measurements>.
  - 8.1.701 START\_LITHO\_INFORMATION — (text) name of <litho\_information>.
  - 8.1.702 START\_MASK\_RESULTS — Indicates the beginning of the file from the vendor to the customer containing actual mask results data. Should match the data field of the START\_ORDER to which it is responding AND the data field of END\_MASK\_RESULTS.
  - 8.1.703 START\_MASK\_RESULTS\_OPTIONS — (text) name of <mask\_results\_options>.
  - 8.1.704 START\_MATERIALS\_USED — (text) name of <materials\_used>.
  - 8.1.705 START\_MEASURED\_REGISTR\_MARK — (text) name of <measured\_registr\_mark>.
  - 8.1.706 START\_OPC — (text) name of <opc\_definition> group.
  - 8.1.707 START\_ORDER — Indicates the beginning of order entry data file from the customer to the vendor. Should indicate the name(s) of the mask sets included.
  - 8.1.708 START\_PATTERN\_GROUP\_RESULTS — (text) name of <pattern\_group\_results>.
  - 8.1.709 START\_PATTERN\_OPTIONS — (text) name of <pattern\_options> group.
  - 8.1.710 START\_PHASE\_ANGLE\_MEASUREMENTS — Indicates the beginning of phase angle measurements within <phase\_shift\_measurements>.
  - 8.1.711 START\_PHASE\_SHIFT — (text) name of <phase\_shift> group.
  - 8.1.712 START\_PHASE\_SHIFT\_MEASUREMENTS — (text) name of <phase\_shift\_measurements> group.
  - 8.1.713 START\_PLACEMENT — (text) name of <placement> group.
  - 8.1.714 START\_REGISTR — Indicates beginning of <registration> collection. Defines separation between multiple <registration>s. Alphanumeric data field identifies the collection to establish which collections are hierarchically superseded by another; also for reference by REGISTR\_RELATIVE.
  - 8.1.715 START\_REGISTR\_MEASUREMENTS — (text) name of <registr\_measurements> group.
  - 8.1.716 START\_REPAIR\_DEFINITION — (text) name of <repair\_definition> group.
  - 8.1.717 START\_SEM\_PHOTO — (text) name of <sem\_photo> group.
  - 8.1.718 START\_SHIP\_PLOT — Indicates beginning of <ship\_plot> collection. Alphanumeric data field identifies the collection to establish which collections are hierarchically affected by another. The appearance of a <ship\_plot> with the same START\_SHIP\_PLOT data field at a lower level in the hierarchy (see §6) supersedes the <ship\_plot> at a higher level in the hierarchy.
  - 8.1.719 START\_SHIP\_TO — (text) name of <ship\_to> group.
  - 8.1.720 START\_SHIPPABLE\_DATA — (text) name of <shippable\_data> group.
  - 8.1.721 START\_SUBSTRATE — (text) name of <substrate> group.
  - 8.1.722 START\_SURFACE\_DEFINITION — (text) name of <surface\_definition> group.
  - 8.1.723 START\_SURFACE\_INSP\_MEASUREMENTS — (text) name of <surface\_insp\_measurements> group.
- Must match START\_SURFACE\_DEFINITION of corresponding <surface\_definition> group.

8.1.724 **START\_TITLE** — (title number) Indicates the beginning keywords for a specific title.

8.1.725 **START\_TRANSMISSION\_MEASUREMENTS** — Indicates the beginning of transmission measurements within <phase\_shift\_measurements>.

8.1.726 **START\_VENDOR\_INFO** — (text) name of <vendor\_info> group.

8.1.727 **STATUS** — (NEW, OLD, CHANGE, CANCEL, HOLD, STOP, RESTART, RETURNED, PROTESTED, QUOTE ONLY) Present status of mask(s); NEW = new mask which has not been ordered before. OLD = previously ordered mask whose data is included for reference only. CHANGE = previously ordered mask whose data is included because the order data has been changed since the last transmission. CANCEL = previously ordered mask whose order is being cancelled. HOLD = enter a new mask but do not release it to production until customer authorization. STOP = previously ordered mask which is put on hold until further notice. RESTART = changes a previous STATUS of STOP from being on hold to being released for production. RETURNED = a previously delivered mask which has been rejected by the customer and is being returned to the vendor. A data entry transmittal which includes a RETURNED mask should also include a NEW mask if replacement is to be initiated. PRICE of the returned mask should be the negative of the original price in order to track credit. The NEW mask should also contain PRICE and a new schedule. PROTESTED = a RETURNED mask whose rejection is protested by the mask vendor. If a NEW mask accompanied the RETURNED mask to initiate replacement, the NEW mask should also have PROTESTED status. QUOTE\_ONLY = the order is not to be manufactured, but is only to be used by the vendor for quoting price and delivery.

8.1.728 **STD\_PATTERN\_NAME** — Name of a standard pattern, on file at the vendor, previously supplied or authorized by the customer.

8.1.729 **STEPPING\_COUNT** — (x,y) Count of successive pattern or cell placements.

8.1.730 **STEPPING\_DISTANCE** — (x,y) Spacing between successive pattern or cell placements.

8.1.731 **STRIPE\_HEIGHT** — Stripe height in address units of pattern file.

8.1.732 **SUMMARY\_FILE\_NAME** — (text) Name identifying the summary output file for RUNSET\_NAME. If this keyword appears in the <mask\_order>, it must be explicitly referenced in a RUNSET\_NAME and/or a PARAMETER\_FILE\_NAME.

8.1.733 **SURF\_DEFECT\_TYPE** — (CONTAM\_ON\_CLEAR, DIM\_CLEAR, ON\_EDGE, UNKOWN, PINHOLE, BRIGHT\_CHROME, CONTAM\_ON\_CHROME, DIM\_CHROME, ON\_CLEAR, BRIGHT, ON\_CHROME, ON\_ATT, DIM\_ATT, ATT\_PINHOLE and others on request) Setup parameter for surface inspection.

8.1.734 **SURF\_INSP\_AREA** — (x1,y1,x2,y2) Unscaled coordinates of window for surface inspection, lower left and upper right corners, relative to the nominal center of mask, pattern or cell (chrome side up for masks, unmirrored for patterns or cells).

8.1.735 **SURF\_INSP\_EQUIP\_REQD** — Alphanumeric identification of acceptable equipment for defect inspection.

8.1.736 **SURF\_INSP\_EQUIP\_USED** — Surface inspection equipment used.

8.1.737 **SURF\_INSP\_GLASS\_SIDE** — If present, specifies the maximum dimension of the smallest unacceptable particle on the glass side of the mask. This keyword is generally intended for non-pelliclized masks.

8.1.738 **SURF\_INSP\_METHOD** — (LASER, VISUAL, PIXEL or MICROSCOPE) Methodology for detecting surface particles.

8.1.739 **SURF\_INSP\_MODE\_REQD** — Alphanumeric operating mode required for SURF\_INSP\_EQUIP\_REQD.

8.1.740 **SURF\_INSP\_MODE\_USED** — (text) SURF\_INSP\_EQUIP\_USED operating mode.

8.1.741 **SURF\_INSP\_PATTERN\_SIDE** — Specifies the maximum dimension of the smallest unacceptable particle on the patterned side of the mask. This keyword is generally intended for non-pelliclized masks.

8.1.742 **SURF\_INSP\_PELL\_BOTTOM** — Specifies the maximum dimension of the smallest unacceptable particle on the pellicle on the glass side of the mask on either surface of the pellicle membrane or on the glass surface under the pellicle.

- 8.1.743 SURF\_INSP\_PELL\_TOP — If present, specifies the maximum dimension of the smallest unacceptable particle on the pellicle on the patterned side of the mask on either surface of the pellicle membrane.
- 8.1.744 SURF\_INSP\_PELL\_TOP\_INSIDE\_MEMBRANE — Maximum dimension of the smallest unacceptable particle on the patterned side of the mask on the inside surface of the pellicle membrane.
- 8.1.745 SURF\_INSP\_PELL\_TOP\_INSIDE\_ON\_FRAME — Maximum dimension of the smallest unacceptable particle on the patterned side of the mask on the inside surface of the pellicle frame.
- 8.1.746 SURF\_INSP\_PELL\_TOP\_ON\_CLEAR\_PATTERN — Maximum dimension of the smallest unacceptable particle on the patterned surface of the mask under the pellicle, but on the clear pattern of the mask.
- 8.1.747 SURF\_INSP\_PELL\_TOP\_ON\_OPAQUE\_PATTERN — Maximum dimension of the smallest unacceptable particle on the patterned surface of the mask under the pellicle, but on the opaque pattern of the mask.
- 8.1.748 SURF\_INSP\_PELL\_TOP\_OUTSIDE\_FRAME — Maximum dimension of the smallest unacceptable particle on the patterned surface of the mask outside the pellicle frame.
- 8.1.749 SURF\_INSP\_PELL\_TOP\_OUTSIDE\_MEMBRANE — Maximum dimension of the smallest unacceptable particle on the patterned side of the mask on the outside surface of the pellicle membrane.
- 8.1.750 SURF\_INSP\_PELL\_TOP\_OUTSIDE\_ON\_FRAME — Maximum dimension of the smallest unacceptable particle on the patterned side of the mask on the outside surface of the pellicle frame.
- 8.1.751 SURF\_INSP\_PELL\_TOP\_OUTSIDE\_ON\_OPAQUE — Maximum dimension of the smallest unacceptable particle on the patterned surface of the mask outside the pellicle frame, but on the opaque surface of the mask.
- 8.1.752 SURF\_INSP\_PIXEL\_SIZE\_REQD — Pixel size to use for surface inspection.
- 8.1.753 SURF\_INSP\_PIXEL\_SIZE\_USED — Pixel size used by SURF\_INSP\_EQUIP\_USED.
- 8.1.754 SURF\_INSP\_SENSITIVITY\_REQD — Sensitivity to be used by SURF\_INSP\_EQUIP\_REQD.
- 8.1.755 SURF\_INSP\_SENSITIVITY\_USED — Sensitivity used by SURF\_INSP\_EQUIP\_USED.
- 8.1.756 SURF\_INSP\_SETUP\_FILE\_NAME\_REQD — Alphanumeric name of setup file for SURF\_INSP\_EQUIP\_REQD.
- 8.1.757 SURF\_INSP\_SETUP\_FILE\_NAME\_USED — Alphanumeric name of setup file for SURF\_INSP\_EQUIP\_USED.
- 8.1.758 SURFACE\_INSPECTION — If present, requires surface inspection and specifies the maximum dimension of the smallest unacceptable surface particles.
- 8.1.759 SURFACE\_QUALITY\_ID — (text) Customer's label for a collection of surface quality specifications, to be used only in addition to explicit quality requirement keywords. This may be used in the data structure in addition to, but not in place of, explicit quality requirement keywords. This may not be used in combination with QUALITY\_GROUP\_ID. Customer and vendor should document the meaning of this quality grade before using it in SEMI P10.
- 8.1.760 SURROUNDING\_HEIGHT — Height of clear or dark border around pattern on mask.
- 8.1.761 SURROUNDING\_TONE — (CLEAR or DARK) Border surrounding pattern on mask is to be either clear or dark.
- 8.1.762 SURROUNDING\_WIDTH — Width of clear or dark border around pattern on mask.
- 8.1.763 THROUGH\_PELLCLE\_DEFECTS — Precedes <defect\_measurements> when delivering defect data measured with pellicle applied.
- 8.1.764 TITLE\_FONT — Alphanumeric name of the font use in writing TITLE\_TEXT, to be previously agreed between customer and vendor.
- 8.1.765 TITLE\_HEIGHT — (height) Height in microns of title characters.



- 8.1.766 TITLE\_JUSTIFICATION — (L or R) Left or right justification within the writable field, before mirroring and before rotation.
- 8.1.767 TITLE\_LOCATION — (x,y) Location of the lower left corner of TITLE\_TEXT in the associated <title\_data> (before mirroring or rotation), relative to nominal center of mask (chrome side up).
- 8.1.768 TITLE\_MAG — Numeric magnification to the standard font size for the mask writer in writing TITLE\_TEXT. This item should not be used in conjunction with TITLE\_HEIGHT for the same MASK\_SET\_ID.
- 8.1.769 TITLE\_TEXT — (text) Alphanumeric contents of human-readable text on the mask.
- 8.1.770 TITLE\_TYPE — (MASK, DEVICE, LAYER, DATE\_TIME, SOFTWARE, SERIAL\_NUMBER, AUXILIARY)
- 8.1.771 TOP\_PELLCLE\_CENTRALITY\_ERROR — (x,y,rotation) Maximum misplacement in micrometers and microradians of pellicle mounting, relative to the nominal center of the mask.
- 8.1.772 TOP\_PELLCLE\_TYPE — Alphanumeric brand and model of acceptable pellicle for the patterned side of the mask. If multiple pellicles are listed, they are prioritized with the most preferred first and least preferred last.
- 8.1.773 TOP\_PELLCLE\_USED — (text) The pellicle vendor's part number of the pellicle applied to the patterned surface of the mask.
- 8.1.774 TRANSMISSION\_DEFECT\_CLEAR — Maximum allowable percent transmission of light through a clear defect.
- 8.1.775 TRANSMISSION\_DEFECT\_DARK — Maximum allowable percent blocking of light through a dark defect.
- 8.1.776 TRANSMISSION\_EQUIP\_REQD — (text) Transmission measurement equipment required by customer.
- 8.1.777 TRANSMISSION\_EQUIP\_USED — (text) Transmission measurement equipment used.
- 8.1.778 TRANSMISSION\_ERROR — For phase shift masks, the maximum acceptable deviation of any percent transmission measurement from the TRANSMISSION\_TARGET.
- 8.1.779 TRANSMISSION\_MARK\_DRAWING — The uniquely identified (for each customer) document which shows the transmission mark structure itself, and may show the place(s) within the transmission mark which are to be measured.
- 8.1.780 TRANSMISSION\_MARK\_FEATURE — Text describing the feature to be used for transmission measurement.
- 8.1.781 TRANSMISSION\_MARK\_LOCATION — (x,y) Location of transmission mark location relative to the nominal center of the mask (chrome side up).
- 8.1.782 TRANSMISSION\_MARK\_LOCATION\_DRAWING — The uniquely identified (for each customer) document which shows the location(s) of the transmission mark structure.
- 8.1.783 TRANSMISSION\_MARK\_SITE\_ID — Unique alphanumeric identifier of each transmission measurement location within MASK\_SET\_ID to identify individual locations when using <mask\_results>. If the same coordinates apply to locations on different masks within the mask set, they may have the same TRANSMISSION\_MARK\_SITE\_ID, but it is not mandatory.
- 8.1.784 TRANSMISSION\_MEASUREMENT\_DATE — Transmission measurement date.
- 8.1.785 TRANSMISSION\_MEASUREMENT\_FILE\_NAME — Name of data file containing results of transmission measurement.
- 8.1.786 TRANSMISSION\_MODE\_REQD — (text) Operating mode required by customer for TRANSMISSION\_EQUIP\_USED.
- 8.1.787 TRANSMISSION\_MODE\_USED — (text) Operating mode used on TRANSMISSION\_EQUIP\_USED operating mode.

8.1.788 TRANSMISSION\_RANGE — For phase shift masks, the maximum acceptable variation of all percent transmission measurements, relative to each other.

8.1.789 TRANSMISSION\_REFERENCE\_ONLY — (T or F) If T, indicates that the transmission feature is to be measured and the data transmitted to the customer (if requested by SHIP\_PHASE\_SHIFT\_MEASUREMENTS), but that deviations in its measured value due to mask processing would NOT be cause for mask rejection.

8.1.790 TRANSMISSION\_TARGET — For phase shift masks, the required percent transmission of light at the specified PSM\_WAVELENGTH compared to quartz.

8.1.791 TRANSMISSION\_TOLERANCE — For phase shift masks, the maximum acceptable deviation of the mean of all percent transmission measurements to the TRANSMISSION\_TARGET.

8.1.792 UNSCALED\_PATTERN\_SIZE — (x,y) Unscaled size of the pattern file. If this is incorrect, the mask will not be written until it is corrected.

8.1.793 USER\_UNIT — To be used for fracturing DATABASE\_SOURCE into inspection data, as required by some inspection systems.

8.1.794 UT1X\_UNCUT — (T or F) If T, indicates that the reticle is to be delivered uncut (i.e., 5 inch square) size. If F, or if the keyword is absent, the reticle is to be delivered in the 3 inch by 5 inch size.

8.1.795 VENDOR — The name of the company from which the masks are ordered.

8.1.796 VENDOR\_ADDRESS — Address for VENDOR\_CONTACT.

8.1.797 VENDOR\_CONTACT — Name of person to contact regarding the mask.

8.1.798 VENDOR\_EMAIL — Internet address for VENDOR.

8.1.799 VENDOR\_FAX — Phone number for facsimile machine of VENDOR.

8.1.800 VENDOR\_ORDER\_ID — (text) The mask vendor's order identification used to track the mask order in manufacturing.

8.1.801 VENDOR\_PHONE — Phone number for VENDOR\_CONTACT.

8.1.802 VIRTUAL\_ADDRESS — (T or F) Designates whether "virtual addressing" option is to be used to write the pattern. If T, then the pattern will be written with a writing grid twice the nominal size of the pattern but in such a way that the overall dimensions of the pattern and its internal features are preserved. This option is used only by MEBES systems and is usually limited to writing grids no larger than 0.25 micron.

8.1.803 VISUAL\_INSP\_CRITERIA — (text) The part of the mask to inspect visually (e.g., "5 mm border").

8.1.804 VISUAL\_INSPECTION\_OK — (T or F) If T, the area of the preceding pattern may be inspected visually and/or automatically at the vendor's option. VISUAL\_INSPECTION\_OK is not allowed if either VISUAL\_INSPECTION\_REQD or AUTO\_INSPECTION\_REQD is T (true).

8.1.805 VISUAL\_INSPECTION\_REQD — (T or F) Visual, microscopic inspection of the mask for defects is required.

8.1.806 WAFER\_EXPOSURE\_ILLUMINATION — (STANDARD, ANNULAR, DIPOLE, QUADRAPOLE, and others on request) Illumination configuration of the scanner, stepper or aligner on which the mask is to be used. If ANNULAR, then both WAFER\_EXPOSURE\_SIGMA\_INNER and WAFER\_EXPOSURE\_SIGMA\_OUTER are required. If not ANNULAR, then only WAFER\_EXPOSURE\_SIGMA is required.

8.1.807 WAFER\_EXPOSURE\_NUMERICAL\_APERATURE — Numerical aperture in nanometers of the scanner, stepper or aligner on which the mask is to be used.

8.1.808 WAFER\_EXPOSURE\_SIGMA — Partial coherence of the scanner, stepper or aligner on which the mask is to be used. (This is a unitless parameter.)

8.1.809 WAFER\_EXPOSURE\_SIGMA\_INNER — Inner partial coherence of the scanner, stepper or aligner on which the mask is to be used. (This is a unitless parameter.)



8.1.810 **WAFER\_EXPOSURE\_SIGMA\_OUTER** — Outer partial coherence of the scanner, stepper or aligner on which the mask is to be used. (This is a unitless parameter.)

8.1.811 **WAFER\_EXPOSURE\_TOOL** — Alphanumeric brand and model of the scanner, stepper or aligner on which the mask is to be used.

8.1.812 **WAFER\_FAB** — (text) Identification of the customer's wafer fab at which the mask(s) are intended to be used.

8.1.813 **WAIVER** — The uniquely identified (for each customer) document which describes specifications which may be ignored by the vendor.

8.1.814 **WAIVER\_OVERRIDE** — The uniquely identified (for each customer) document which describes specifications which usually may be ignored by the vendor, but in this case may NOT be ignored by the vendor. This keyword cancels the effect of the waiver only within the scope of its application in <mask\_order>.

8.1.815 **WEB\_ADDRESS** — URL address.

8.1.816 **WRITE\_DATE\_TIME** — Date and time at which mask exposure began on the lithography tool.

## 9 Computing the Checksum

9.1 The cyclic checksum is computed as follows:

9.1.1 Initialize the 16 bit checksum value to zero. Consider all the records in the data file from **START\_ORDER** through **END\_ORDER**, inclusive. Consider each ASCII character up to and including the "new\_line" character. Convert each character to its ASCII numeric equivalent (e.g., space is 32 decimal, "A" is 65 decimal, etc.) Use the value 10 decimal for the new\_line function regardless of its internal representation (e.g., CR LF). Use only the 7 bit ASCII representation for each character (i.e., ignore the high order bit in an 8 bit byte).


9.1.2 XOR each of the characters from each of the records in sequence, from the first character in the **START\_ORDER** record to the new\_line character in the **END\_ORDER** record. Before each character is XORed with the checksum, circularly rotate the previous value of the accumulated 16 bit checksum one bit to the left.

9.1.3 After all of the above characters have been accumulated into the checksum, convert it as an unsigned 16 bit integer into the ASCII representation of its decimal value. This ASCII string is the data field following the **CHECKSUM** keyword, the last record in the mask order structure.


## RELATED INFORMATION 1

### CRITICAL DIMENSION KEYWORDS


**NOTICE:** This related information is not an official part of SEMI P10 and was derived from the North American Microlithography Committee. This related information was approved for publication by full letter ballot on April 22, 2004.




**CD\_TOLERANCE** — Maximum acceptable deviation of the mean of all measured critical dimensions to the CD\_TARGET




**CD\_DEVIATION\_FROM\_MEAN** — Maximum acceptable deviation of any of the customer-required CD measurements from the mean of those measurements.




**CD\_RANGE** — Maximum acceptable variation of all measured critical dimensions of same nominal size, same tone and same orientation, relative to each other.




**CD\_THREE\_SIGMA** — Maximum acceptable 3-sigma deviation of all measured critical dimensions to the mean of all measured critical dimensions



**CD\_XY\_DEVIATION** — Maximum deviation, on a site-by-site basis, of a horizontal critical dimension to a vertical critical dimension. The two critical dimensions at each site must be the same size in the pattern data and the same tone on the mask.




**CD\_XY\_TOLERANCE** — Maximum acceptable deviation of the mean of all measured horizontal critical dimensions to the mean of all measured vertical mask critical dimensions. Critical dimensions at all sites must be the same size in the pattern data.



**CD\_DEVIATION\_FROM\_TARGET** — Maximum acceptable deviation of any of the customer-required CD measurements from the CD\_TARGET.

If only one data value (p) appears in the data field, the tolerance is considered +/- symmetrically about CD\_TARGET.



If two data values ( p [,m] ) appear, then the first is the maximum amount by which deviation is allowed larger than CD\_TARGET, and the second is the maximum amount by which deviation is allowed smaller than CD\_TARGET. The comma and second half of the argument are optional in the syntax (p[,m]) where p = the plus and m = the minus value for non-symmetric tolerances; if only p is specified, the plus and minus values are assumed to be symmetric.




## RELATED INFORMATION 2

### SEMI PHOTOMASK ORDER DATA FILE EXAMPLE

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

**EXAMPLE:** A pair of 4-die 5X reticles with separate scribe, barcode, and rms alignment marks. Critical dimensions are defined as pattern options.





START_ORDER	MS999	
SEMI_REVISION	P10-0704	!<mask_order>
CUSTOMER	COMPANY NAME	
VENDOR	ULTIMATE MASK COMPANY	
FILE_DATE_TIME	13-APR-1992, 13:00:00Z	
MASK_SET_ID	9999	!<mask_set>
BILLING_CONTACT	Jean Doe, Accounts Payable	!<mask_set_options>
BILLING_ADDRESS	Company Name	
BILLING_ADDRESS	Street Address	
BILLING_ADDRESS	City, State ZIP	
BILLING_PHONE	4085551212	
PRICE_UNITS	USD	
SHIPPING_CONTACT	Joe Doe, Wafer Fab	
SHIPPING_ADDRESS	Company Name	
SHIPPING_ADDRESS	Street Address	
SHIPPING_ADDRESS	City, State ZIP	
SHIP_CD_DATA	T	
START_SHIP_TO	CD	
EMAIL_ADDRESS	CD_Engineer@Fab.com	
END_SHIP_TO	CD	
SHIP_CD_DATA	T	
START_SHIP_TO	CD Data	
EMAIL_ADDRESS	MaskEngineer@Fab.com	
END_SHIP_TO	CD Data	
DATA_MEDIUM	9 TRACK_TAPE	
DATA_ID	DEVICE 9999	
DATA_FORMAT	MEBES	
DATA_DENSITY	1600BPI	
DATA_PATTERN_NAME	VT9999X-1A-26	
PATTERN_FORMAT	MEBES_RETICLE	
DATA_PATTERN_NAME	VT9999X-1A-10	
PATTERN_FORMAT	MEBES_RETICLE	
DATA_PATTERN_NAME	SC9999X-1A-26	
PATTERN_FORMAT	MEBES_RETICLE	
DATA_PATTERN_NAME	SC9999X-1A-10	
PATTERN_FORMAT	MEBES_RETICLE	
END_DATA_MEDIUM	9 TRACK_TAPE	
STD_PATTERN_NAME	GCARMSB-OX-AA	
PATTERN_FORMAT	MEBES_RETICLE	
END_MASK_SET_OPTIONS	9999	
!		
MASK_GROUP_ID	5X	!<mask_group>
BLANKET_PO_NUMBER	101055C	
RELEASE_NUMBER	42	
MILESTONES	T	



PRODUCT_TYPE	RETICLE	
PRODUCT_MAGNIFICATION	5X	
PRODUCT_IMAGING_TYPE	BINARY	
TITLE_TYPE	DEVICE	
TITLE_LOCATION	12500,58500	
END_TITLE	1	
START_TITLE	2	
TITLE_TYPE	MASK	
TITLE_LOCATION	12500,56500	
END_TITLE	2	
START_BARCODE	A	
BARCODE_TYPE	GCA	
BARCODE_LOCATION	-50000,57500	
END_BARCODE	A	
MIRROR_MASK	T	
START_SUBSTRATE	S1	
BLANK_SIZE	5/90	
BLANK_TYPE	ULTE	
BLANK_FLATNESS	2	
MASK_COATING	LOW_REFLECTANCE_CHROME	
RESIST_TYPE	POSITIVE	
END_SUBSTRATE	S1	
START_REGISTR	RG1	
REGISTR_ERROR	0.25	
REGISTR_REF_MASK_ID	2	
END_REGISTR	RG1	
START_CD	SPECIFICATION	
CD_TOLERANCE	0.25	
CD_RANGE	0.3	
END_CD	SPECIFICATION	
START_DEFECT_DEFINITION	C	
DEFECT_SIZE	2.0	
DEFECT_COUNT	0	
INSPECTION_AREA	-30000,-35000,30000,35000	
END_DEFECT	C	
PACKAGE	H60-51-63A09	
END_MASK_GROUP_OPTIONS	5X	
!		
PLACEMENT_TOP_CELL	C1	
!		
MASK_ID	1	!<mask_definition>
DELIVERABLE_MASK	T	
LINE_ITEM_NUMBER	1	
STATUS	NEW	
DUE_DATE_TIME_REQUESTED	1992-04-20, 14:00Z	



PRICE	2000	
START_TITLE	2	
TITLE_TEXT	DIFFUSION	
END_TITLE	2	
START_BARCODE	A	
BARCODE_TEXT	9999-26	
END_BARCODE	A	
MIN_MASK_FEATURE_SIZE	10	
END_MASK	1	
!		
MASK_ID	2	!<mask_definition>
DELIVERABLE_MASK	T	
LINE_ITEM_NUMBER	2	
STATUS	NEW	
DUE_DATE_TIME_REQUESTED	1992-04-21, 14:00Z	
PRICE	2000	
PRICE_UNITS	USD	
START_TITLE	2	
TITLE_TEXT	POLY	
END_TITLE	2	
START_BARCODE	A	
BARCODE_TEXT	9999-10	
END_BARCODE	A	
MIN_MASK_FEATURE_SIZE	10	
END_MASK	2	
!		
CELL_ID	C1	!<cell_definition>
END_CELL_OPTIONS	C1	
CELL_INSTANCE	C2	!MAIN ARRAY
END_CELL_INSTANCE_OPTIONS	C2	
START_PLACEMENT	P2	
LOCATION	0,0	
END_PLACEMENT	P2	
END_CELL_INSTANCE	C2	
PATTERN_GROUP_INSTANCE	PG3	!RMS ALIGNMENT KEYS
START_PLACEMENT	PG3	
LOCATION	0,-57500	
LOCATION	-11000,57500	
END_PLACEMENT	PG3	
END_CELL	C1	!END TOP CELL DEFINITION
!		
CELL_ID	C2	!MAIN ARRAY DEFINITION
END_CELL_OPTIONS	C2	
PATTERN_GROUP_INSTANCE	PG1	!PRIMARY DIE

START_PLACEMENT	PG1	
LOCATION	-15000,-17500	
STEPPING_DISTANCE	30000,35000	
STEPPING_COUNT	2,2	
END_PLACEMENT	PG1	
END_PATTERN_GROUP_INSTANCE	PG1	
PATTERN_GROUP_INSTANCE	PG2	!SCRIBE LINE
START_PLACEMENT	PG2	
LOCATION	0,0	
END_PLACEMENT	PG2	
END_PATTERN_GROUP_INSTANCE	PG2	
END_CELL	C2	
!		
PATTERN_GROUP_ID	PG1	!PRIMARY PATTERN GROUP
START_PATTERN_OPTIONS	PTN1	
PATTERN_ADDRESS_SIZE	0.5	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	25000,30000	
END_PATTERN_OPTIONS	PTN1	
END_PATTERN_GROUP_OPTIONS	PG1	
LEVEL_ID	1	
PATTERN_NAME	VT9999X-1A-26	
START_PATTERN_OPTIONS	PTN1.26	
DIGITIZED_DATA_DARK	T	
END_PATTERN_OPTIONS	PTN1.26	
END_PATTERN_DEFINITION	1	
LEVEL_ID	2	
PATTERN_NAME	VT9999X-1A-10	
START_PATTERN_OPTIONS	PTN1.10	
DIGITIZED_DATA_DARK	F	
END_PATTERN_OPTIONS	PTN1.10	
END_PATTERN_DEFINITION	2	
END_PATTERN_GROUP	PG1	
!		
PATTERN_GROUP_ID	PG2	!SCRIBE PATTERN GROUP
START_PATTERN_OPTIONS	PTN2	
PATTERN_ADDRESS_SIZE	0.5	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	65000,75000	
START_CD	CD_SITES_1	
CD_SITE_ID	CD_1	
CD_LOCATION	-40000,0	
END_CD	CD_SITE_1	



START_CD	CD_SITE_2	
CD_SITE_ID	CD_2	
CD_LOCATION	0,-40000	
END_CD	CD_SITE_2	
START_CD	CD_SITE_3	
CD_SITE_ID	CD_3	
CD_LOCATION	0,40000	
END_CD	CD_SITE_3	
START_CD	CD_SITE_4	
CD_SITE_ID	CD_4	
CD_LOCATION	0,0	
END_CD	CD_SITE_4	
END_PATTERN_OPTIONS	PTN2	
END_PATTERN_GROUP_OPTIONS	PG2	
LEVEL_ID	1	
PATTERN_NAME	SC9999X-1A-26	
START_PATTERN_OPTIONS	PO.26	
DIGITIZED_DATA_DARK	T	
START_CD	DIMENSION	
CD_DATA	10	
CD_DIGITIZED	T	
CD_TARGET	10	
END_CD	DIMENSION	
END_PATTERN_OPTIONS	PO.26	
END_PATTERN_DEFINITION	1	
LEVEL_ID	2	
PATTERN_NAME	SC9999X-1A-10	
START_PATTERN_OPTIONS	PO.10	
DIGITIZED_DATA_DARK	F	
START_CD	DIMENSION	
CD_DATA	10	
CD_DIGITIZED	T	
CD_TARGET	10.5	
END_CD	DIMENSION	
END_PATTERN_OPTIONS	PO.10	
END_PATTERN_DEFINITION	2	
END_PATTERN_GROUP	PG2	!END SCRIBE GROUP
!		
PATTERN_GROUP_ID	PG3	!RMS ALIGNMENT MARK
START_PATTERN_OPTIONS	PTN3	
PATTERN_ADDRESS_SIZE	0.5	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	2000,2000	
START_DEFECT_DEFINITION	DD.1	



INSPECTION_AREA	-3000,-3000,3000,3000	
END_DEFECT_DEFINITION	DD.1	
END_PATTERN_OPTIONS	PTN3	
END_PATTERN_GROUP_OPTIONS	PG3	
LEVEL_ID	A	
PATTERN_NAME	GCARMSB-OX-AA	
START_PATTERN_OPTIONS	PTN3.AA	
DIGITIZED_DATA_DARK	F	
END_PATTERN_OPTIONS	PTN3.AA	
END_PATTERN_DEFINITION	A	
END_PATTERN_GROUP	PG3	!END ALIGNMENT MARK
!		
END_MASK_GROUP	5X	
END_MASK_SET	9999	
END_ORDER	MS9999	
CHECKSUM	computed checksum	



### RELATED INFORMATION 3

## SEMI PHOTOMASK ORDER DATA FILE EXAMPLE EMPLOYING MULTIPLE WRITE AND PROCESS STEPS FOR A SINGLE MASK

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

EXAMPLE: One 4-die phase shift reticle requiring two write and process steps.

START_ORDER	MS999	
SEMI_REVISION	P10-0704	!<mask_order>
CUSTOMER	COMPANY NAME	
VENDOR	ULTIMATE MASK COMPANY	
FILE_DATE_TIME	06-JUL-2000, 01:06:00	
MASK_SET_ID	9999	!<mask_set>
END_MASK_SET_OPTIONS	9999	
!		
MASK_GROUP_ID	PSM	!<mask_group>
START_TITLE	1	
TITLE_TEXT	DEVICE 9999	
TITLE_TYPE	DEVICE	
TITLE_LOCATION	12500,58500	
END_TITLE	1	
START_TITLE	2	
TITLE_TEXT	PHASE SHIFT POLY	
TITLE_TYPE	MASK	
TITLE_LOCATION	12500,56500	
END_TITLE	2	
MIRROR_MASK	T	
PRODUCT_TYPE	RETICLE	
PRODUCT_MAGNIFICATION	5X	
PRODUCT_IMAGING_TYPE	EAPSM	
BLANK_SIZE	6/250	
BLANK_TYPE	ULTE	
BLANK_FLATNESS	1	
MASK_COATING	MOSI	
RESIST_TYPE	POSITIVE	
START_CD	SPECIFICATION	
CD_TOLERANCE	0.05	
CD_RANGE	0.06	
END_CD	SPECIFICATION	
END_MASK_GROUP_OPTIONS	5X	
!		
PLACEMENT_TOP_CELL	C1	
!		



MASK_ID	1	!First write and process step
DELIVERABLE_MASK	F	
MULTIWRITE	(1,1)	
START_PHASE_SHIFT	1	
PSM_WAVELENGTH	248	
TRANSMISSION_TARGET	6	
TRANSMISSION_TOLERANCE	0.4	
TRANSMISSION_RANGE	0.8	
PHASE_ANGLE_TARGET	180	
PHASE_ANGLE_TOLERANCE	4	
PHASE_ANGLE_RANGE	8	
END_PHASE_SHIFT	1	
START_REGISTR	1	
REGISTR_ERROR	0.10	
END_REGISTR	1	
MIN_MASK_FEATURE_SIZE	0.8	
END_MASK	1	
!		
MASK_ID	2	!Second write and process step
DELIVERABLE_MASK	T	
MULTIWRITE	(1,2)	
START_PHASE_SHIFT	2	
PSM_WAVELENGTH	248	
TRANSMISSION_TARGET	6	
TRANSMISSION_TOLERANCE	0.4	
TRANSMISSION_RANGE	0.8	
PHASE_ANGLE_TARGET	180	
PHASE_ANGLE_TOLERANCE	4	
PHASE_ANGLE_RANGE	8	
END_PHASE_SHIFT	2	
TOP_PELLCLE_TYPE	CA627P-7043L	
MIN_MASK_FEATURE_SIZE	0.8	
START_DEFECT_DEFINITION	C	
DEFECT_SIZE	0.3	
DEFECT_COUNT	0	
INSPECTION_AREA	-30000,-35000,30000,35000	
END_DEFECT	C	
END_MASK	2	
!		
CELL_ID	C1	!<cell_definition>
END_CELL_OPTIONS	C1	
CELL_INSTANCE	C2	!MAIN ARRAY
END_CELL_INSTANCE	C2	
LOCATION	0,0	
PATTERN_GROUP_INSTANCE	PG3	!RMS ALIGNMENT KEYS



LOCATION	0,-57500	
LOCATION	-11000,57500	
END_CELL	C1	!END TOP CELL DEFINITION
!		
CELL_ID	C2	!MAIN ARRAY DEFINITION
END_CELL_OPTIONS	C2	
PATTERN_GROUP_INSTANCE	PG1	!PRIMARY DIE
LOCATION	-15000,-17500	
STEPPING_DISTANCE	30000,35000	
STEPPING_COUNT	2,2	
PATTERN_GROUP_INSTANCE	PG2	!SCRIBE LINE
LOCATION	0,0	
END_CELL	C2	
!		
PATTERN_GROUP_ID	PG1	!PRIMARY PATTERN GROUP
PATTERN_ADDRESS_SIZE	0.05	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	25000,30000	
END_PATTERN_GROUP_OPTIONS	PG1	
LEVEL_ID	1	
PATTERN_NAME	VT9999X-1A-26	
DIGITIZED_DATA_DARK	T	
END_PATTERN_DEFINITION	1	
LEVEL_ID	2	
PATTERN_NAME	VT9999X-1A-10	
DIGITIZED_DATA_DARK	F	
END_PATTERN_DEFINITION	2	
END_PATTERN_GROUP	PG1	
!		
PATTERN_GROUP_ID	PG2	!SCRIBE PATTERN GROUP
PATTERN_ADDRESS_SIZE	0.05	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	65000,75000	
START_CD	CD_SITES	
CD_SITE_ID	CD_1	
CD_LOCATION	-40000,0	
CD_SITE_ID	CD_2	
CD_LOCATION	0,-40000	
CD_SITE_ID	CD_3	
CD_LOCATION	0,40000	
CD_SITE_ID	CD_4	
CD_LOCATION	0,0	
END_CD	CD_SITES	



END_PATTERN_GROUP_OPTIONS	PG2	
LEVEL_ID	1	
PATTERN_NAME	SC9999X-1A-26	
DIGITIZED_DATA_DARK	T	
START_CD	DIMENSION	
CD_DATA	0.8	
CD_DIGITIZED	T	
CD_TARGET	0.8	
END_CD	DIMENSION	
END_PATTERN_DEFINITION	1	
LEVEL_ID	2	
PATTERN_NAME	SC9999X-1A-10	
DIGITIZED_DATA_DARK	F	
START_CD	DIMENSION	
CD_DATA	0.8	
CD_DIGITIZED	T	
CD_TARGET	0.8	
END_CD	DIMENSION	
END_PATTERN_DEFINITION	2	
END_PATTERN_GROUP	PG2	!END SCRIBE GROUP
!		
PATTERN_GROUP_ID	PG3	!RMS ALIGNMENT MARK
PATTERN_ADDRESS_SIZE	0.5	
SCALE_FACTOR	1.0	
STRIPE_HEIGHT	1024	
UNSCALED_PATTERN_SIZE	2000,2000	
INSPECTION_AREA	-3000,-3000,3000,3000	
END_PATTERN_GROUP_OPTIONS	PG3	
LEVEL_ID	A	
PATTERN_NAME	GCARMSB-OX-AA	
DIGITIZED_DATA_DARK	F	
END_PATTERN_DEFINITION	A	
END_PATTERN_GROUP	PG3	!END ALIGNMENT MARK
!		
END_MASK_GROUP	PSM	
END_MASK_SET	9999	
END_ORDER	MS9999	
CHECKSUM	computed checksum	



## RELATED INFORMATION 4

### SEMI PHOTOMASK MASK RESULTS DATA FILE EXAMPLE

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

EXAMPLE: The actual mask CD data sent by the vendor to the customer for a 4-die 5X reticle with SHIP\_CD\_DATA set to TRUE. (For reference, see Related Information 2, for MASK\_ID = 1.)

START_MASK_RESULTS	MS999	
SEMI_REVISION	P10-0704	!<mask_order>
CUSTOMER	COMPANY NAME	
VENDOR	ULTIMATE MASK COMPANY	
FILE_DATE_TIME	13-APR-1992, 13:00:00	
MASK_SET_ID	9999	!<mask_set>
MASK_GROUP_ID	5X	
MASK_ID	1	
TITLE_TEXT	DEVICE 9999	
TITLE_TEXT	DIFFUSION	
START_CD_GROUP_MEASUREMENTS	SPECIFICATION	
CD_TARGET	10	
CD_TOLERANCE	0.25	
CD_RANGE	0.3	
START_CD_MEASUREMENT	CD_1	
CD_SITE_ID	CD_1	
CD_LOCATION	-40000,0	
MEASURED_CD_SITE_ID	CD_1	
MEASURED_CD_LOCATION	-40000.1,0.08	
MEASURED_CD	9.95	
END_CD_MEASUREMENT	CD_1	
START_CD_MEASUREMENT	CD_2	
CD_SITE_ID	CD_2	
CD_LOCATION	0,-40000	
MEASURED_CD_SITE_ID	CD_2	
MEASURED_CD_LOCATION	-0.07,-40000.11	
MEASURED_CD	10.01	
END_CD_MEASUREMENT	CD_2	
START_CD_MEASUREMENT	CD_3	
CD_SITE_ID	CD_3	
CD_LOCATION	0,40000	
MEASURED_CD_LOCATION	0.03,39999.95	
MEASURED_CD	9.98	
END_CD_MEASUREMENT	CD_3	
START_CD_MEASUREMENT	CD_4	
CD_SITE_ID	CD_4	
CD_LOCATION	0,0	



MEASURED_CD_SITE_ID	CD_4
MEASURED_CD_LOCATION	0.01,-0.04
MEASURED_CD	10.07
END_CD_MEASUREMENT	CD_4
END_CD_GROUP_MEASUREMENTS	SPECIFICATION
END_MASK	1
END_MASK_GROUP	5X
END_MASK_SET	9999
END_ORDER	MS9999
CHECKSUM	computed checksum



## RELATED INFORMATION 5

### SEMI PHOTOMASK ORDER EXAMPLE FOR 5X RETICLES

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

! Sample of 5X reticle order corresponding to recent practices

!

START_ORDER	O555555	
SEMI_REVISION	P10-0704	
CUSTOMER	CUSTOMER NAME	
VENDOR	ACME PHOTOMASKS	
FILE_DATE_TIME	14-Oct-2002, 10:39:26	
!		
MASK_SET_ID	S55555	
!		
BUSINESS_CONTACT	ORDER FROM CONTACT NAME	
BUSINESS_ADDRESS	ORDER FROM ADDRESS LINE1	!Use as few or as
BUSINESS_ADDRESS	ORDER FROM ADDRESS LINE2	!many lines as
BUSINESS_ADDRESS	ORDER FROM ADDRESS LINE3	!needed - min=1
BUSINESS_PHONE	555-555-5555	
BUSINESS_FAX	555-555-5555	
BUSINESS_EMAIL	BUSINESS EMAIL ADDRESS	
!		
BILLING_CONTACT	BILL CONTACT NAME	
BILLING_ADDRESS	BILL ADDRESS LINE1	!Use as few or as
BILLING_ADDRESS	BILL ADDRESS LINE2	!many lines as
BILLING_ADDRESS	BILL ADDRESS LINE3	!needed - min=1
BILLING_PHONE	555-555-5555	
BILLING_FAX	555-555-5555	
BILLING_EMAIL	BILL EMAIL ADDRESS	
!		
DESIGN_RULE	0.35	
PRICE_UNITS	USD	
!		
ENGINEERING_CONTACT	ENGR CONTACT NAME	
ENGINEERING_ADDRESS	ENGR ADDRESS LINE1	!Use as few or as
ENGINEERING_ADDRESS	ENGR ADDRESS LINE2	!many lines as
ENGINEERING_ADDRESS	ENGR ADDRESS LINE3	!needed - min=1
ENGINEERING_PHONE	555-555-5555	
ENGINEERING_FAX	555-555-5555	
ENGINEERING_EMAIL	ENGR EMAIL ADDRESS	
!		
SHIPPING_CONTACT	SHIP CONTACT NAME	
SHIPPING_ADDRESS	SHIP ADDRESS LINE1	
SHIPPING_ADDRESS	SHIP ADDRESS LINE2	
SHIPPING_PHONE	555-555-5555	
SHIPPING_FAX	555-555-5555	
SHIPPING_EMAIL	EMAIL ADDRESS	
!		
!		
SHIPPING_METHOD	COURIER NAME	
SHIPPING_METHOD	TERMS	
!		
REPAIRS_AUTHORIZED	T	
!		
START_SHIPPABLE_DATA	S1	
SHIP_CD_DATA	T	
START_SHIP_TO	S1CD	! <different shipto address>



MAILING_ADDRESS	123 SOMEWHERE ELSE ST.
MAILING_ADDRESS	A CITY
MAILING_ADDRESS	THE STATE, THE ZIP
MAILING_ADDRESS	COUNTRY
END_SHIP_TO	S1CD
SHIP_DEFECT_DATA	T
SHIP_THRU_PELLCLE_DATA	T
SHIP_INSP_DATABASE_DATA	F
SHIP_REPAIR_DATA	T
SHIP_REGISTR_DATA	T
END_SHIPPABLE_DATA	S1
!	
!	
DATA_MEDIUM	FTP
DATA_FILE_SIZE	12121212
DATA_PATTERN_NAME	FILENAME.01
PATTERN_FORMAT	MEBES_RETICLE
DATA_PATTERN_WINDOW	0.0, 0.0, 34555.500, 10987.500
END_DATA_PATTERN_NAME	FILENAME.01
END_DATA_MEDIUM	FTP
!	
DATA_MEDIUM	FTP
DATA_FILE_SIZE	12171212
DATA_PATTERN_NAME	FILENAME.02
PATTERN_FORMAT	MEBES_RETICLE
DATA_PATTERN_WINDOW	0.0, 0.0, 34555.500, 10987.500
END_DATA_PATTERN_NAME	FILENAME.02
END_DATA_MEDIUM	FTP
!	
DATA_MEDIUM	FTP
DATA_FILE_SIZE	13101056
DATA_PATTERN_NAME	FILENAME.03
PATTERN_FORMAT	MEBES_RETICLE
DATA_PATTERN_WINDOW	0.0, 0.0, 34555.500, 10987.500
END_DATA_PATTERN_NAME	FILENAME.03
END_DATA_MEDIUM	FTP
!	
! MET2ALL	
DATA_MEDIUM	FTP
DATA_FILE_SIZE	13101058
DATA_PATTERN_NAME	FILENAME.04
PATTERN_FORMAT	MEBES_RETICLE
DATA_PATTERN_WINDOW	0.0, 0.0, 34555.500, 10987.500
END_DATA_PATTERN_NAME	FILENAME.04
END_DATA_MEDIUM	FTP
!	
MASK_SET_NAME	DEVICE NAME
ORDER_ID	ORDER ID NUMBER
!	
END_MASK_SET_OPTIONS	S55555
!	
MASK_GROUP_ID	G5555
PO_NUMBER	P.O. NUMBER
!	
PRODUCT_TYPE	RETICLE
PRODUCT_MAGNIFICATION	5X
PRODUCT_IMAGING_TYPE	BINARY
!	
END_MASK_GROUP_OPTIONS	G5555
!	
PLACEMENT_TOP_CELL	TC
!	



MASK_ID	M111	
MASK_NAME	CONTACT 1	
DELIVERABLE_MASK	T	
STATUS	NEW	
DUE_DATE_TIME_REQUESTED	24-Oct-2002, 10:39:26	
LAYER_PRIORITY	1	
PRICE	15000	
LITHO_EQUIP_REQD	EBEAM	
JOB_NAME	JOBDECK NAME	
JOB_LEVEL	1	
!		
START_TITLE	1	
TITLE_TEXT	TITLE TEXT	
TITLE_TYPE	MASK	
TITLE_JUSTIFICATION	L	
TITLE_LOCATION	13400, 8650	
ROTATE_TITLE	90	
END_TITLE	1	
!		
START_TITLE	2	
TITLE_TEXT	DEVICE NAME	
TITLE_TYPE	DEVICE	
TITLE_JUSTIFICATION	L	
TITLE_LOCATION	14400, 8050	
ROTATE_TITLE	90	
END_TITLE	2	
!		
START_TITLE	3	
TITLE_TEXT	CUSTOMER PROPRIETARY	
TITLE_TYPE	AUXILIARY	
TITLE_JUSTIFICATION	L	
TITLE_LOCATION	14700, 2000	
ROTATE_TITLE	90	
END_TITLE	3	
!		
START_BARCODE	1	
BARCODE_TYPE	ASM	
BARCODE_TEXT	BARCODE TEXT	
BARCODE_LOCATION	63000,55000	
BARCODE_ROTATION	0	
END_BARCODE	1	
!		
START_BARCODE	2	
BARCODE_TYPE	CANON	
BARCODE_TEXT	BARCODE TEXT	
BARCODE_LOCATION	-62222,-22000	
BARCODE_ROTATION	0	
END_BARCODE	2	
!		
MIRROR_MASK	T	
BLANK_SIZE	6/250	
BLANK_TYPE	ULTE	
BLANK_FLATNESS	2	
MASK_COATING	LOW_REFLECTIVE_CHROME	
RESIST_TYPE	POSITIVE	
!		
TOP_PELLICLE_TYPE	PELLICLE PART NUMBER1	!First choice
TOP_PELLICLE_TYPE	PELLICLE PART NUMBER2	!Second choice
!		
START_REGISTR	1	
REGISTR_ERROR	10	
REGISTR_REF_METHOD_REQD	PTB	





REGISTR_ALGORITHM	MULTI-POINT
MASK_REGISTR_MARK	0,0
MEASURE_FILE_NAME	MEASURE FILENAME
END_REGISTR	1
!	
MIN_MASK_FEATURE_SIZE	15
!	
START_DEFECT_DEFINITION	1
VISUAL_INSPECTION_REQD	F
AUTO_INSPECTION_REQD	T
DEFECT_SIZE	0.75
DEFECT_COUNT	0
!	
INSPECTION_AREA	-54388, -54388, 53994, 56053
DATABASE_INSPECTION	T
END_DEFECT_DEFINITION	1
!	
!	
SURF_INSP_METHOD	LASER
SURF_INSP_PELL_TOP	1.0
SURF_INSP_PELL_BOTTOM	1.0
SURF_INSP_GLASS_SIDE	2.0
SURF_INSP_PATTERN_SIDE	.75
!	
!	
INSPECT_THROUGH_PELLCLE	T
!	
START_DEFECT_DEFINITION	2
DIE_TO_DIE_INSPECTION	T
DEFECT_SIZE	1.50
DEFECT_COUNT	0
DATABASE_INSPECTION	T
END_DEFECT_DEFINITION	2
!	
QUALITY_GROUP_ID	Q1
PACKAGE	COMPACT PART NUMBER
!	
END_MASK	M111
!	
!	
MASK_ID	M222
MASK_NAME	METAL 1
DELIVERABLE_MASK	T
STATUS	NEW
DUE_DATE_TIME_REQUESTED	26-Oct-2002, 10:39:26
LAYER_PRIORITY	1
PRICE	10000
LITHO_EQUIP_REQD	EBEAM
JOB_NAME	JOBDECK NAME
JOB_LEVEL	1
!	
START_TITLE	1
TITLE_TEXT	TITLE TEXT
TITLE_TYPE	MASK
TITLE_JUSTIFICATION	L
TITLE_LOCATION	13400, 86500
ROTATE_TITLE	90
END_TITLE	1
!	
START_TITLE	2
TITLE_TEXT	DEVICE NAME
TITLE_TYPE	DEVICE



TITLE_JUSTIFICATION	L
TITLE_LOCATION	14400, 80500
ROTATE_TITLE	90
END_TITLE	2
!	
START_TITLE	3
TITLE_TEXT	CUSTOMER PROPRIETARY
TITLE_TYPE	AUXILIARY
TITLE_JUSTIFICATION	L
TITLE_LOCATION	14700, 20000
ROTATE_TITLE	90
END_TITLE	3
!	
START_BARCODE	1
BARCODE_TYPE	ASM
BARCODE_TEXT	BARCODE TEXT
BARCODE_LOCATION	63000,32000
BARCODE_ROTATION	0
END_BARCODE	1
!	
START_BARCODE	2
BARCODE_TYPE	CANON
BARCODE_TEXT	BARCODE TEXT
BARCODE_LOCATION	-62222,-22000
BARCODE_ROTATION	0
END_BARCODE	2
!	
MIRROR_MASK	T
BLANK_SIZE	6/250
BLANK_TYPE	ULTE
BLANK_FLATNESS	2.0
MASK_COATING	LOW_REFLECTIVE_CHROME
RESIST_TYPE	POSITIVE
!	
TOP_PELLCLE_TYPE	PELLICLE PART NUMBER1
TOP_PELLCLE_TYPE	PELLICLE PART NUMBER2
!	
START_REGISTR	1
REGISTR_ERROR	10
REGISTR_REF_METHOD_REQD	PTB
REGISTR_ALGORITHM	MULTI-POINT
MASK_REGISTR_MARK	0,0
MEASURE_FILE_NAME	MEASURE FILENAME
END_REGISTR	1
!	
MIN_MASK_FEATURE_SIZE	.25
!	
START_DEFECT_DEFINITION	1
VISUAL_INSPECTION_REQD	F
AUTO_INSPECTION_REQD	T
DEFECT_SIZE	0.85
DEFECT_COUNT	0
!	
INSPECTION_AREA	-59388, -57388, 51994, 53053
DATABASE_INSPECTION	T
END_DEFECT_DEFINITION	1
!	
!	
SURF_INSP_METHOD	LASER
SURF_INSP_PELL_TOP	1.0
SURF_INSP_PELL_BOTTOM	1.0
SURF_INSP_GLASS_SIDE	2.0

SURF_INSP_PATTERN_SIDE	.75
!	
!	
INSPECT_THROUGH_PELLCLE	T
!	
START_DEFECT_DEFINITION	2
DIE_TO_DIE_INSPECTION	T
DEFECT_SIZE	1.50
DEFECT_COUNT	0
DATABASE_INSPECTION	T
END_DEFECT_DEFINITION	2
!	
QUALITY_GROUP_ID	Q1
PACKAGE	COMPACT PART NUMBER
!	
END_MASK	M222
!	
!	
CELL_ID	TC
END_CELL_OPTIONS	TC
!	
PATTERN_GROUP_INSTANCE	PRIMARY
START_PLACEMENT	1
LOCATION	0.000, 0.000
STEPPING_DISTANCE	0, 0
STEPPING_COUNT	1, 1
END_PLACEMENT	1
END_PATTERN_GROUP_INSTANCE	PRIMARY
!	
PATTERN_GROUP_INSTANCE	CLEAR_BOX
START_PLACEMENT	CBP1
LOCATION	33000, -33000
STEPPING_DISTANCE	0, 0
STEPPING_COUNT	1, 1
END_PLACEMENT	CBP1
!	
START_PLACEMENT	CBP2
LOCATION	-33000, 33000
STEPPING_DISTANCE	0, 0
END_PLACEMENT	CBP2
STEPPING_COUNT	1, 1
END_PATTERN_GROUP_INSTANCE	CLEAR_BOX
!	
PATTERN_GROUP_INSTANCE	FID
START_PLACEMENT	FP1
LOCATION	60000, 60000
STEPPING_DISTANCE	0, 0
STEPPING_COUNT	1, 1
END_PLACEMENT	FP1
END_PATTERN_GROUP_INSTANCE	FID
!	
END_CELL	TC
!	
!	
PATTERN_GROUP_ID	PRIMARY
END_PATTERN_GROUP_OPTIONS	PRIMARY
!	
LEVEL_ID	M111
PATTERN_NAME	FILESNAME.01
START_PATTERN_OPTIONS	1PPO
PATTERN_ADDRESS_SIZE	0.25
DIGITIZED_DATA_DARK	F

!	
START_CD	1
CD_DATA	1.250
CD_DIGITIZED	T
CD_TONE_CLEAR	T
CD_TARGET	1.300
CD_ORIENTATION	HORIZONTAL
CD_REFERENCE_ONLY	F
CD_TOLERANCE	.12
CD_RANGE	.12
NUMBER_OF_CDS	4
CD_LOCATION	-53448.100, -43783.375
CD_LOCATION	-53448.100, 55576.625
CD_LOCATION	-49070.125, -53343.000
CD_LOCATION	-49070.125, 47017.000
CD_FEATURE	TUNING FORK
END_CD	1
END_PATTERN_OPTIONS	1PPO
END_PATTERN_DEFINITION	M111
!	
LEVEL_ID	M222
PATTERN_NAME	FILENAME.02
START_PATTERN_OPTIONS	2PPO
PATTERN_ADDRESS_SIZE	0.25
DIGITIZED_DATA_DARK	T
!	
START_CD	1
CD_DATA	2.25
CD_DIGITIZED	T
CD_TONE_CLEAR	T
CD_TARGET	2.30
CD_ORIENTATION	HORIZONTAL
CD_REFERENCE_ONLY	F
CD_TOLERANCE	.12
CD_RANGE	.12
NUMBER_OF_CDS	4
CD_LOCATION	-33448.100, -53783.375
CD_LOCATION	-33448.100, 45576.625
CD_LOCATION	-39070.125, -13343.000
CD_LOCATION	-39070.125, 27017.000
CD_FEATURE	L BAR
END_CD	1
END_PATTERN_OPTIONS	2PPO
END_PATTERN_DEFINITION	M222
!	
END_PATTERN_GROUP	PRIMARY
!	
!	
PATTERN_GROUP_ID	CLEAR_BOX ! Only for Mask M111
END_PATTERN_GROUP_OPTIONS	CLEAR_BOX
!	
LEVEL_ID	M111
PATTERN_NAME	FILENAME.03
START_PATTERN_OPTIONS	1CPO
PATTERN_ADDRESS_SIZE	0.25
DIGITIZED_DATA_DARK	F
END_PATTERN_OPTIONS	1CPO
END_PATTERN_DEFINITION	M111
!	
END_PATTERN_GROUP	CLEAR_BOX
!	
PATTERN_GROUP_ID	FID



PATTERN_ADDRESS_SIZE	0.25
END_PATTERN_GROUP_OPTIONS	FID
!	
LEVEL_ID	M111
PATTERN_NAME	FILENAME.04
START_PATTERN_OPTIONS	1CPO
DIGITIZED_DATA_DARK	F
END_PATTERN_OPTIONS	1CPO
END_PATTERN_DEFINITION	M111
!	
LEVEL_ID	M222
PATTERN_NAME	FILENAME.04
START_PATTERN_OPTIONS	2CPO
DIGITIZED_DATA_DARK	T
END_PATTERN_OPTIONS	2CPO
END_PATTERN_DEFINITION	M222
!	
END_PATTERN_GROUP	FID
!	
!	
END_MASK_GROUP	G5555
END_MASK_SET	S55555
END_ORDER	O555555
CHECKSUM	118



## RELATED INFORMATION 6

### SEMI PHOTOMASK ORDER EXAMPLE FOR UT1X RETICLES

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

!NOTE: Indentation is for clarity only and is not required.

!

START_ORDER	ORDER11111
SEMI_REVISION	P10-0704
CUSTOMER	AAA CUSTOMER
VENDOR	ANY VENDOR
FILE_DATE_TIME	01-Jan-2002, 12:00
OPERATOR_NAME	AN OPERATOR
!	
MASK_SET_ID	ABC123
BILLING_CONTACT	CONTACT NAME
BILLING_ADDRESS	BILLING ADDRESS LINE 1
BILLING_ADDRESS	BILLING ADDRESS LINE 2
PRICE_UNITS	USD
SHIPPING_CONTACT	CONTACT NAME
SHIPPING_ADDRESS	SHIPPING ADDRESS LINE 1
SHIPPING_ADDRESS	SHIPPING ADDRESS LINE 2
SHIPPING_ADDRESS	SHIPPING ADDRESS LINE 3

!

DATA_MEDIUM	FTP
DATA_PATTERN_NAME	FILENAME01.1\$
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME01.1\$
DATA_PATTERN_NAME	FILENAME01.2\$
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME01.2\$
DATA_PATTERN_NAME	FILENAME02.1\$
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME02.1\$
DATA_PATTERN_NAME	FILENAME03.50
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME03.50
DATA_PATTERN_NAME	FILENAME04.50
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME04.50
DATA_PATTERN_NAME	FILENAME05.S\$
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME05.S\$
DATA_PATTERN_NAME	FILENAME06.25
PATTERN_FORMAT	MEBES_RETICLE
END_DATA_PATTERN_NAME	FILENAME06.25
END_DATA_MEDIUM	FTP



```
!  
MASK_SET_NAME          ABC123  
MASK_SET_VERSION       ABC123  
!  
END_MASK_SET_OPTIONS   ABC123  
!  
MASK_GROUP_ID          UT1X_GROUP_1  
END_MASK_GROUP_OPTIONS UT1X_GROUP_1  
!  
PLACEMENT_TOP_CELL     UT_1X_TOP_CELL  
!  
!-----MASKS-----  
MASK_ID                100001  
MASK_NAME              NAME100001  
DELIVERABLE_MASK      T  
PO_NUMBER              123456789  
RELEASE_NUMBER         987654  
STATUS                 NEW  
DUE_DATE_TIME_REQUESTED 01-Jan-2002, 10:44  
PRICE                  1111.0  
REPAIRS_AUTHORIZED     T  
!  
START_SHIPPABLE_DATA   1  
SHIP_CD_PRINTOUT       T  
SHIP_DEFECT_DATA       T  
SHIP_REGISTR_DATA      T  
END_SHIPPABLE_DATA     1  
!  
PRODUCT_TYPE           1X_STD_FIELD_RETICLE  
PRODUCT_MAGNIFICATION  1X  
PRODUCT_IMAGING_TYPE   BINARY  
QUANTITY                1  
WAFER_EXPOSURE_TOOL     ULTRATECH  
JOB_NAME                j1000001.jb  
JOB_LEVEL               1  
!  
START_TITLE            TITLE_1  
TITLE_TEXT             ABC123  
TITLE_TYPE             DEVICE  
TITLE_JUSTIFICATION     L  
TITLE_LOCATION          -33000.0, -1000.0  
MIRROR_TITLE           F  
ROTATE_TITLE           0  
ROTATE_TITLE_CHARACTERS 0  
END_TITLE              TITLE_1  
!  
START_TITLE            TITLE_2  
TITLE_TEXT             NAME100001
```



TITLE_TYPE	MASK
TITLE_JUSTIFICATION	L
TITLE_LOCATION	-22000.0, 1000.0
MIRROR_TITLE	F
ROTATE_TITLE	0
ROTATE_TITLE_CHARACTERS	0
END_TITLE	TITLE_2
!(	
MIRROR_MASK	T
BLANK_SIZE	5/90
BLANK_TYPE	ULTE
BLANK_FLATNESS	2
MASK_COATING	LOW_REFLECTIVE_CHROME
UT1X_UNCUT	T
TOP_PELLCLE_TYPE	Pellicle Part Number
GUIDES_REQD	STANDARD
!	
START_DEFECT_DEFINITION	UT1X_1
GOOD_FIELDS	(1 AND 2)
END_DEFECT_DEFINITION	UT1X_1
!	
START_DEFECT_DEFINITION	PREPELL_DIE2DIE_1
AUTO_INSPECTION_REQD	T
DIE_TO_DIE_INSPECTION	T
DEFECT_SIZE_CL	1.0
DEFECT_SIZE_DK	1.0
DEFECT_COUNT	0
END_DEFECT_DEFINITION	PREPELL_DIE2DIE_1
!	
QUALITY_GROUP_ID	ABC123
PACKAGE	Package Part Number
END_MASK	1000001

!-----

!

! The TOP\_CELL's role in the P10 Standard is to provide a means to list and locate all of the  
! Patterns on the Mask. Within the TOP\_CELL Cell ID section (below) both Patterns and other Cells  
! can be listed. The value for the Top Cell is given by the PLACEMENT\_TOP\_CELL keyword in the  
! MASK\_GROUP section above.

!

! This example lays out each component of the Mask using the "CELL\_INSTANCE" keyword.  
! Each Ultratech Field is represented by a "FLD\_x" designation for a Cell Instance, where "x" is  
! the field number. The general idea is to designate a cell for each Field separately and to let  
! the MASK\_PATTERNS cell hold the remaining data. In this example the FLD\_1 cell contains Field 1,  
! the FLD\_2 cell holds Field 2, and the MASK\_PATTERNS cell holds Barcode, BOJ, EOJ, Fiducial,  
! and Logo data. Other types of Patterns could also be included in the MASK\_PATTERNS cell.

!

!

!-----CELLS-----





CELL_ID	UT_1X_TOP_CELL	!-- refers to PLACEMENT_TOP_CELL
END_CELL_OPTIONS	UT_1X_TOP_CELL	
!		
CELL_INSTANCE	FLD_1	!--Field 1 cell within TOP_CELL
END_CELL_INSTANCE_OPTIONS	FLD_1	
START_PLACEMENT	F1	
LOCATION	-32000.0, 28000.0	
END_PLACEMENT	F1	
END_CELL_INSTANCE	FLD_1	
!		
CELL_INSTANCE	FLD_2	!--Field 2 cell within TOP_CELL
END_CELL_INSTANCE_OPTIONS	FLD_2	
START_PLACEMENT	F2	
LOCATION	25500.0, 28500.0	
END_PLACEMENT	F2	
END_CELL_INSTANCE	FLD_2	
!		
CELL_INSTANCE	MASK_PATTERNS	!--Other data cell with TOP_CELL
END_CELL_INSTANCE_OPTIONS	MASK_PATTERNS	
END_CELL_INSTANCE	MASK_PATTERNS	
END_CELL	UT_1X_TOP_CELL	
!		
!		
! Each CELL_ID below lists the components in that cell, using the PATTERN_GROUP_INSTANCE keyword,		
! along with placement data.		
!		
! Field 1		
CELL_ID	FLD_1	!--This refers to CELL_INSTANCE FLD_1
END_CELL_OPTIONS	FLD_1	
!		
PATTERN_GROUP_INSTANCE	FLD_1_PG	
START_PLACEMENT	FDPN1	
LOCATION	-20000.0, 20000.0	
STEPPING_DISTANCE	10000.0, 0.0	
STEPPING_COUNT	2, 1	
END_PLACEMENT	FDP_1	
END_PATTERN_GROUP_INSTANCE	FLD_1_PG	
END_CELL	FLD_1	
!		
! Field 2		
CELL_ID	FLD_2	!--This refers to CELL_INSTANCE FLD_2
END_CELL_OPTIONS	FLD_2	
!		
PATTERN_GROUP_INSTANCE	FLD_2_PG	
START_PLACEMENT	FDP_2	
LOCATION	50000.0, 20000.0	
STEPPING_DISTANCE	0.0, 0.0	
STEPPING_COUNT	1, 1	



END_PLACEMENT	FDP_2	
END_PATTERN_GROUP_INSTANCE	FLD_2_PG	
END_CELL	FLD_2	
!		
CELL_ID	MASK_PATTERNS	!--This refers to CELL_INSTANCE
		!MASK_PATTERNS
END_CELL_OPTIONS	MASK_PATTERNS	
!		
PATTERN_GROUP_INSTANCE	BARCODES	
START_PLACEMENT	BC_1	
LOCATION	85500.000, 113350.000	
STEPPING_DISTANCE	0.0, 0.0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	BC_1	
END_PATTERN_GROUP_INSTANCE	BARCODES	
!		
PATTERN_GROUP_INSTANCE	BOJ	
START_PLACEMENT	BJ_1	
LOCATION	119000, 88000	
STEPPING_DISTANCE	0.0, 0.0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	BJ_1	
START_PLACEMENT	BJ_2	
LOCATION	9700, 37000	
STEPPING_DISTANCE	0, 0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	BJ_2	
END_PATTERN_GROUP_INSTANCE	BOJ	
!		
PATTERN_GROUP_INSTANCE	EOJ	
START_PLACEMENT	EJ_1	
LOCATION	119000, 88000	
STEPPING_DISTANCE	0.0, 0.0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	EJ_1	
START_PLACEMENT	EJ_2	
LOCATION	9800, 3800	
STEPPING_DISTANCE	0, 0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	EJ_2	
END_PATTERN_GROUP_INSTANCE	EOJ	
!		
PATTERN_GROUP_INSTANCE	FIDUCIAL	
START_PLACEMENT	FD_1	
LOCATION	63500, 63500	
STEPPING_DISTANCE	0.0, 0.0	
STEPPING_COUNT	1, 1	
END_PLACEMENT	FD_1	
END_PATTERN_GROUP_INSTANCE	FIDUCIAL	

```

!
PATTERN_GROUP_INSTANCE      LOGO
  START_PLACEMENT           LG_1
    LOCATION                 10000, 7500
    STEPPING_DISTANCE        0.0, 0.0
    STEPPING_COUNT           1, 1
  END_PLACEMENT              LG_1
END_PATTERN_GROUP_INSTANCE   LOGO
!
END_CELL                     MASK_PATTERNS
!-----
!
! The PATTERN_GROUP_ID section relates patterns to specific groups of Masks. The LEVEL_ID
! value MUST agree with a specific MASK_ID value. When multiple Masks are ordered, there
! will be multiple LEVEL_ID sections within each PATTERN_GROUP_ID section.
!
! The PATTERN_NAME values should agree with those listed in the DATA_MEDIUM section.
!
!-----PATTERN_GROUPS-----
! Field 1
PATTERN_GROUP_ID             FLD_1_PG      !refers to PATTERN_GROUP_INSTANCE FLD_1_PG
END_PATTERN_GROUP_OPTIONS    FLD_1_PG
!
LEVEL_ID                     1000001
PATTERN_NAME                  FILENAME01.1$
START_PATTERN_OPTIONS         FLD_1_1
  PATTERN_ADDRESS_SIZE        0.25
  SCALE_FACTOR                 1.0
  DIGITIZED_DATA_DARK         T
  UNSCALED_PATTERN_SIZE       15000.0, 15000.0
  MIRROR_PATTERN              F
END_PATTERN_OPTIONS           FLD_1_1
END_PATTERN_DEFINITION        1000001
END_PATTERN_GROUP            FLD_1_PG
!
! Field 2
PATTERN_GROUP_ID             FLD_2_PG      !refers to PATTERN_GROUP_INSTANCE FLD_2_PG
END_PATTERN_GROUP_OPTIONS    FLD_2_PG
!
LEVEL_ID                     100001
PATTERN_NAME                  FILENAME01.2$
START_PATTERN_OPTIONS         FLD2_2
  PATTERN_ADDRESS_SIZE        0.25
  SCALE_FACTOR                 1.0
  DIGITIZED_DATA_DARK         F
  UNSCALED_PATTERN_SIZE       15000.0, 15000.0
  MIRROR_PATTERN              F
END_PATTERN_OPTIONS           FLD2_2

```



```
END_PATTERN_DEFINITION      1000001
END_PATTERN_GROUP           FLD_2_PG
!
! BARCODE Component
PATTERN_GROUP_ID            BARCODES
END_PATTERN_GROUP_OPTIONS   BARCODES
!
LEVEL_ID                    1000001
PATTERN_NAME                FILENAME02.1$
START_PATTERN_OPTIONS       BC1
  PATTERN_ADDRESS_SIZE      0.25
  DIGITIZED_DATA_DARK       F
END_PATTERN_OPTIONS         BC1
END_PATTERN_DEFINITION      1000001
!
END_PATTERN_GROUP           BARCODES
!
! BOJ Component
PATTERN_GROUP_ID            BOJ
END_PATTERN_GROUP_OPTIONS   BOJ
!
LEVEL_ID                    1000001
PATTERN_NAME                FILENAME03.50
START_PATTERN_OPTIONS       BJ1
  PATTERN_ADDRESS_SIZE      0.250
  DIGITIZED_DATA_DARK       F
END_PATTERN_OPTIONS         BJ1
END_PATTERN_DEFINITION      1000001
!
END_PATTERN_GROUP           BOJ
!
! EOJ Component
PATTERN_GROUP_ID            EOJ
END_PATTERN_GROUP_OPTIONS   EOJ
!
LEVEL_ID                    1000001
PATTERN_NAME                FILENAME04.50
START_PATTERN_OPTIONS       EJ1
  PATTERN_ADDRESS_SIZE      0.250
  DIGITIZED_DATA_DARK       F
END_PATTERN_OPTIONS         EJ1
END_PATTERN_DEFINITION      1000001
!
END_PATTERN_GROUP           EOJ
!
! Fiducial Component
PATTERN_GROUP_ID            FID
END_PATTERN_GROUP_OPTIONS   FID
```

```

!
LEVEL_ID                1000001
PATTERN_NAME            FILENAME05.S$
START_PATTERN_OPTIONS   FL1
  PATTERN_ADDRESS_SIZE  .25
  DIGITIZED_DATA_DARK   F
END_PATTERN_OPTIONS     FL1
END_PATTERN_DEFINITION   1000001
!
END_PATTERN_GROUP       FID
!
! LOGO Component
PATTERN_GROUP_ID        LOGO
END_PATTERN_GROUP_OPTIONS LOGO
!
LEVEL_ID                1000001
PATTERN_NAME            FILENAME06.25
START_PATTERN_OPTIONS   LO1
  PATTERN_ADDRESS_SIZE  .25
  DIGITIZED_DATA_DARK   F
END_PATTERN_OPTIONS     LO1
END_PATTERN_DEFINITION   1000001
!
END_PATTERN_GROUP       LOGO
!-----
!
END_MASK_GROUP          UTIX_GROUP_1
!
END_MASK_SET            ABC123
!
END_ORDER              ORDER1111
CHECKSUM                0

```

## RELATED INFORMATION 7

### EXAMPLE OF A COMPLEX BOOLEAN FUNCTION

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

The following is an excerpt of a P10 file which demonstrates how the <data\_manipulation> capability may be applied.

```

DATA_PATTERN_NAME          METAL-1
PATTERN_FORMAT             MEBES
!-----
-----
START_DATA_MANIPULATION    1
BOOLEAN                    MINUS
!
DATA_SOURCE_FILE           source1.gds
DATA_FORMAT                GDSII
DATA_TOP_CELL              gds_top_cell
DATA_LAYER_ID              1;0
DATA_PATTERN_WINDOW        012600,-13000,-12600,13000
START_DATA_FRACTURE        1
PATTERN_ADDRESS_SIZE       .05
END_DATA_FRACTURE          1
END_DATA_SOURCE_FILE       source1.gds
!
DATA_SOURCE_FILE           source1.gds
DATA_FORMAT                GDSII
DATA_TOP_CELL              gds_top_cell
DATA_LAYER_ID              2;0
DATA_PATTERN_WINDOW        012600,-13000,-12600,13000
START_DATA_FRACTURE        1
PATTERN_ADDRESS_SIZE       .05
END_DATA_FRACTURE          1
END_DATA_SOURCE_FILE       source1.gds
!
END_DATA_MANIPULATION      1
!
START_DATA_MANIPULATION    2
BOOLEAN                    MINUS
!
DATA_SOURCE_FILE           source1.gds
DATA_FORMAT                GDSII
DATA_TOP_CELL              gds_top_cell
DATA_LAYER_ID              3;0
DATA_PATTERN_WINDOW        012600,-13000,-12600,13000
START_DATA_FRACTURE        1
PATTERN_ADDRESS_SIZE       .05
END_DATA_FRACTURE          1
END_DATA_SOURCE_FILE       source1.gds
!
DATA_SOURCE_FILE           source1.gds
DATA_FORMAT                GDSII
DATA_TOP_CELL              gds_top_cell
DATA_LAYER_ID              4;0

```



```

DATA_PATTERN_WINDOW          012600,-13000,-12600,13000
START_DATA_FRACTURE          1
    PATTERN_ADDRESS_SIZE      .05
    END_DATA_FRACTURE          1
END_DATA_SOURCE_FILE          source1.gds
!
END_DATA_MANIPULATION        2
!-----
START_DATA_MANIPULATION      3
    BOOLEAN                    AND      !Note:The input to manipulation 3 is the output
from                                ! manipulations #1 and #2. Discrete names of
temporary files                    !are not required, just a reference to a
previous manipulation.              !This represents the output from both 1 and 2
                                   ! (1-2) and (3-4) with the logical operation of
andng them                          ! together ((1-2)*(3-4)).
    DATA_SOURCE_FILE          1
    DATA_FORMAT               DATA_MANIPULATION
END_DATA_SOURCE_FILE          1
!
    DATA_SOURCE_FILE          2
    DATA_FORMAT               DATA_MANIPULATION
END_DATA_SOURCE_FILE          2
END_DATA_MANIPULATION        3
!-----
START_DATA_MANIPULATION      4
    BOOLEAN                    OR
!
    DATA_SOURCE_FILE          source1.gds
    DATA_FORMAT               GDSII
    DATA_TOP_CELL             gds_top_cell
    DATA_LAYER_ID             6;0
    DATA_PATTERN_WINDOW       012600,-13000,-12600,13000
    START_DATA_FRACTURE        1
        PATTERN_ADDRESS_SIZE    .05
        END_DATA_FRACTURE        1
END_DATA_SOURCE_FILE          source1.gds
!
    DATA_SOURCE_FILE          3
    DATA_FORMAT               DATA_MANIPULATION
END_DATA_SOURCE_FILE          3
!
END_DATA_MANIPULATION        4
!-----
START_DATA_MANIPULATION      5
    BOOLEAN                    AND
!
    DATA_SOURCE_FILE          source1.gds
    DATA_FORMAT               GDSII
    DATA_TOP_CELL             gds_top_cell
    DATA_LAYER_ID             5-7
    DATA_PATTERN_WINDOW       012600,-13000,-12600,13000
    START_DATA_FRACTURE        1

```



```

        PATTERN_ADDRESS_SIZE      .05
    END_DATA_FRACTURE              1
END_DATA_SOURCE_FILE              source1.gds
!
DATA_SOURCE_FILE                  source1.gds
    DATA_FORMAT                   GDSII
    DATA_TOP_CELL                 gds_top_cell
    DATA_LAYER_ID                 17-19;8-9
    DATA_PATTERN_WINDOW           112600,-13000,-112600,13000
    START_DATA_FRACTURE            1
        PATTERN_ADDRESS_SIZE      .05
    END_DATA_FRACTURE              1
END_DATA_SOURCE_FILE              source1.gds
!
DATA_SOURCE_FILE                  4
    DATA_FORMAT                   DATA_MANIPULATION
END_DATA_SOURCE_FILE              4
!
!   Note:  The final sizing, output address size, and data scale are shown
below.
!
    START_DATA_FRACTURE            2
        PATTERN_ADDRESS_SIZE      .05
        DATA_SCALE_FACTOR         5
    END_DATA_FRACTURE              2
!
START_DATA_FRACTURE                3
    SIZING                         .25
        SIZING_RULE                TWOSIDED
        SIZING_BORDER_RULE         PARAGON
END_DATA_FRACTURE                  3
!
    END_DATA_MANIPULATION          5
!-----
-----
END_DATA_PATTERN_NAME              METAL-1
```



## RELATED INFORMATION 8

### EXAMPLE OF A DATA FUNCTION

**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the standard.

The following is an excerpt of a P10 file which demonstrates how the <data\_function> capability might be applied.

```
START_DATA_FUNCTION                                CPL
  DATA_FUNCTION_PURPOSE                           CPL Mask Synthesis for Poly-Gate Layer
  SOFTWARE_NAME                                    MaskWeaver
  SOFTWARE_REVISION                                1.2
  RUNSET_NAME                                       cpl090.mw
  RUNSET_REVISION                                  1.4
  DATA_LOCATION                                   /n/raidhost/r5/mwlib/
    PARAMETER_FILE_NAME                           cpl090.par
    PARAMETER_FILE_REVISION                        2.2
  INPUT_FILE_NAME                                  qtiac90_1.5.gds
  INPUT_FILE_FORMAT                                gds
  TOP_CELL                                         MASTER
  DATA_LOCATION                                   /n/raidhost/r8/tapeouts/qtiac90_1.5/
  RESULT_FILE_NAME                                 qtiac90_1.5_cpl.o32
  SUMMARY_FILE_NAME                                qtiac90_1.5_cpl.sum
  LOG_FILE_NAME                                    qtiac_90_1.5_cpl.log
END_DATA_FUNCTION                                CPL
```


## RELATED INFORMATION 9

### SEMI PHOTOMASK MASK ORDER STRUCTURE TREE DIAGRAM


**NOTICE:** The information contained in this related information is not an official part of SEMI P10, and it is not intended to modify or supercede the official standard. Rather, this example is offered as an aid to visualizing possible output from software which might implement the <mask\_order> portion of the standard in XML format.

**NOTE:** All portions of the tree were scaled to fit within single pages. In cases where a portion of the tree is very long, this causes the text to be very small. Such portions of the tree will be more easily read by viewing them with a text editor or text viewer and using an increased magnification.

#### complexType **AerialImageDataType**




#### complexType **BarcodeDataType**




# complexType **CdDefinitionType**


diagram



# complexType **CdGroupType**




# complexType **CdIsoDenseDefinitionType**




# complexType **CdSetType**

diagram




# complexType **CdXyDefinitionType**


diagram




complexType **CdXySiteType**




complexType **CellDefinitionType**




complexType **CellInstanceType**



# complexType **DatabaseInspectionType**




# complexType **DataFileParametersType**




complexType **DataFractureType**

diagram






# complexType **DataFunctionType**



# complexType **DataManipulationType**



# complexType **DataType**

diagram

